

Hoist Hooks

Campbell hoist hooks are all drop-forged and heat treated. All hooks are drilled for latch assembly.

(1st letter indicates material, number is type, last letter indicates finish)

Eye Hoist - Unlatched	**C-1010-S, A-1010-0**
Eye Hoist - Latched	**C-1015-S, C-1015-G, A-1015-0**
Swivel Hoist - Unlatched	**C-1013-S, A-1013-0**
Swivel Hoist - Latched	**C-1014-S, A-1014-0**



SWIVEL HOIST HOOK



EYE HOIST HOOK

READ AND UNDERSTAND THESE WARNINGS AND INSTRUCTIONS BEFORE USING HOIST HOOKS.

IMPORTANT: Instructions For Use

1. For hooks with latches, the latch is only designed to retain slings and rigging attachments. The latch must not support the load.
2. Swivel hoist hooks are not designed to swivel under load.
3. Do not exceed working load limit (WLL). See table right.

Working Load Limits Hooks

Size	Carbon Steel WLL Ton	Carbon Steel WLL kg	Alloy WLL Ton	Alloy WLL kg
2/22	3/4	680	1	907
3/23	1	907	11/2	1361
4/24	1-1/2	1361	2	1814
5/25	2	1814	3	2722
6/26	2-1/2	2268	4	3629
7/27	3	2722	5	4082
9/29	5	4536	7	6350
11/31	7-1/2	6804	11	9979
12/32	10	9072	15	13608
34	-	-	22	19958

⚠ WARNING

- Failure to follow the instructions for use and these warnings may cause death or serious injury.
- Use hoist hooks only as indicated.
- Never point load a hook.
- Do not use hooks for lifting personnel.
- Hooks must always be inspected for wear, distortion and damage before use. If worn, distorted or damaged, discard and replace.
- Do not weld on hooks. If a hook is exposed to weld spatter, discard that hook.
- Always stand clear of loads being lifted.